
## **VIVA SPECIFICATION**

\*Note: The distance between the connection centres equals the length of the radiator



\*If used with Vaporo Valves.\*

Please note due to manufacturing tolerances pipe centres may vary by +/- 10mm, we recommend that pipe work is not altered until your radiator is on site.